current

Serene Remote Overview

RGBW - Press keys adjust color spectrums.

Main Power & Default - Turns controller and components OFF/ON. Press & hold for 5 seconds to reset controller to factory defaults

RESUME TIMER - Press to turn system/lights back to Timer mode. (Works in Timer B Mode Only)

LOCK/UNLOCK - Locks settings so other IR signals will not interfere. Press and holdfor 5 seconds to LOCK/UNLOCK.

Volume - Changes audio volume. Level 0=OFF, press to adjust 1-5 levels (20% each) Press to MUTE.

TIMER A/B - Switches light from Timer A Mode (Daily On/Off Only) to Timer B Mode (Circadian 24 hr. Timer with slow ramp/dim)

Custom Scene - Press to display custom scene of Main LED Light, Background LED light and audio sound.

Set Clock/Time of Day - Press once to Set Clock and program current time of day.

ON Time - Press once to program ON Time.

HOUR + - Press to adjust hours.

OFF Time - Press once to program OFF Time.

MINUTE- Press to adjust minutes.

ENTER - Press enter after any time is programmed or color spectrum (Daylight, Sunrise, Moonlight, Custom Scene)

DAYLIGHT - Press once to adjust daylight color spectrum, adjust with RGBW keys. When complete, press ENTER.

SUNRISE - Press once to adjust sunrise color spectrum, adjust with RGBW keys. When complete, press ENTER.

MOONLIGHT - Press once to adjust moon color spectrum, adjust with RGBW keys. When complete, press ENTER.

Audio - Press to select audio on-demand,

Dynamic Effects - Press to select on-demand dynamic lighting program.

B/G Light ON/OFF - Press to once to toggle background lighting 50% Brightness / 100% Brightness / OFF

RGB Fade/Color - Press to select RGB fade, Press again to stop at a static color and save using M key.

B/G Light - Press to select background lighting fade program,